





1. Here is a typical pan tilt wiring diagram:



A few pictures for above wiring:





2. How to connect PTZ keyboard controller with pan tilt based on RS485 interface.
Connect RS485A and RS485B from the pan tilt base with the RS485A and RS485B interface at the keyboard for direct pan tilt control.



